



**THIS SIDE
TOWARDS
RADIATOR**



BRP 951

- 1 - INSTALL LOWER PULLEY**
- 2 - INSTALL WATER PUMP PUL**
- 3 - CHECK ALIGNMENT WITH S
EDGE, SOME ENGINES REQ
#953 SPACER BEHIND LOWI
PULLEY**
- 4 - INSTALL PUMP MOUNT TO I
HEAD.**
- 5 - PULL POWER STEERING PI
ONTO PUMP WITH CENTER
LINE UP WITH OTHER PULL
A STRAIGHT EDGE TO LINE
PULLEYS.**
- 6 - INSTALL BELT AND CONFIF
ONLY TIGHTEN BELT ENOU
SLIPPAGE, THESE BELTS D
TO BE OVER TIGHT.**
- 7 - AFTER WARMING UP ENGIN
ALL BOLTS AND ADJUSTMI**

****CHECK EVERYTHING AFTER**